


# MITSUBISHI

## A1S66ADA Analog Input/output Module

### Mitsubishi General Use PLC User's Manual (Hardware)

Thank you for buying the Mitsubishi General Use PLC MELSEC-A Series. Before use, please read this manual carefully and correctly operate the module with a sufficient understanding of the A series PLC functions and performance. Please place this manual in a location where it is available to end users.



MODEL	A1S66ADA-U-H-E
MODEL CODE	13JL42

©1998 MITSUBISHI ELECTRIC CORPORATION IB (NA)-66820-G (0609) MEE

### SAFETY PRECAUTIONS

(Read these precautions before using.)


When using Mitsubishi equipment, thoroughly read this manual and the associated manuals introduced in the manual. Also pay careful attention to safety and handle the module properly.

The instructions given in this manual are concerned with this product. Refer to the User's Manual of the CPU module in use for details on the safety instructions for the programmable logic controller system.

These SAFETY PRECAUTIONS classify the safety precautions into two categories: "DANGER" and "CAUTION".



Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.



Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by CAUTION may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

### DESIGN PRECAUTIONS

#### DANGER

- In case of the external power supply failure or the programmable controller (PLC) failure, set up a safety circuit outside the PLC so that the entire system can operate safely. The mis-output and malfunction may cause an accident.

#### CAUTION

- Use the PLC in an environment that meets the general specifications contained in this manual. Using this PLC in an environment outside the range of the general specifications could result in electric shock, fires, malfunctions, and damage to or deterioration of the product.
- Do not bunch the control wires with the main circuit or power wires, or install them close to each other. They should be installed 100 mm (3.9 inch) or more from each other. Failure to do so may result in noise that would cause malfunctions.
- At power ON/OFF, voltage or current may instantaneously be output from the output terminal of this module. In such case, wait until the analog output becomes stable to start controlling the external device.

### INSTALLATION PRECAUTIONS

#### CAUTION

- Insert the tabs at the bottom of the module into the mounting holes in the base unit. If the module is not properly installed, it may result in malfunctions, failure, or fallout.
- Do not directly touch the module's conductive parts. Doing so could cause malfunctions or failure in the module.

### WIRING PRECAUTIONS

#### CAUTION

- Ground the AG and FG terminals to the protected grounding conductor when there are a lot of noise. Failure to ground these terminals may cause malfunctions.
- When wiring PLC, check the rated voltage and terminal layout of the wiring, and make sure the wiring is done correctly. Connecting a power supply that differs from the rated voltage or wiring it incorrectly may cause fires or failure.
- Tighten the terminal screws within the range of specified torque. If the terminal screws are loose, it may result in short circuits or malfunctions. Tightening the screws too far may cause damage to the screw, resulting in short circuits, or malfunctions.
- Be sure there are no foreign substances such as sawdust or wiring debris inside the module. Such debris could cause fires, failure, malfunctions.

### STARTING AND MAINTENANCE PRECAUTIONS

#### CAUTION

- Do not touch the connector while the power is on. Doing so could cause malfunctions.
- Make sure to switch all phases of the external power supply off before cleaning or re-tightening terminal screws. If you do not switch off the external power supply, it will cause failure or malfunctions of the module.
- Do not disassemble or modify the modules. Doing so could cause failure, malfunctions, injury, or fires.
- Make sure to switch all phases of the external power supply off before mounting or removing the module. If you do not switch off the external power supply, it will cause failure or malfunctions of the module.
- Do not install/remove the terminal block more than 50 times after the first use of the product. (IEC 61131-2 compliant)
- Before handling the module, always touch grounded metal, etc. to discharge static electricity from the human body. Failure to do so can cause the module to fail or malfunction.

### OPERATING PRECAUTIONS

#### DANGER

- Do not output (turn ON) the "usage disable" signal as an output signal to special modules from the PLC CPU. Outputting the "usage disable" signal may cause PLC system malfunctions.

### DISPOSAL PRECAUTIONS

#### CAUTION

- When disposing of this product, treat it as industrial waste.

### About This Manual

The following product manuals are available.

Related Manual	Manual Name	Manual No. (Type code)
	Analog Input/output Module type A1S66ADA User's Manual	IB-66819 (13JL41)

Please read A1S66ADA Module User's Manual before using this module.

### 1. Overview

This manual describes the handling and specifications of the A1S66ADA type Analog I/O Module (hereafter referred to as A1S66ADA), which is utilized in combination with the MELSEC-A series CPU module (hereafter referred to as PLC CPU).

- Product in the same package  
After unpacking, please confirm that the following product is contained.

Product Name	No. of Items
Analog Input/output Module type A1S66ADA	1

### 2. Performance Specifications

The performance specifications of the A1S66ADA are described below.

Item	Performance Specifications					
	Voltage output			Current output		
Digital input	0 to 4000 (12-bit binary value)					
Analog output	-10 to 10VDC (External load resistance: 2kΩ to 1MΩ)			0 to 20mA (External load resistance: 0Ω to 600Ω)		
	Digital input	Analog output		Digital input	Analog output	
I/O characteristics	0	0V	0V	1V	-10V	0
	1000	2.5V	1.25V	2V	-5V	1000
	2000	5V	2.5V	3V	0V	2000
	3000	7.5V	3.75V	4V	5V	3000
	4000	10V	5V	5V	10V	4000
Maximum resolution	2.5mV	1.25mV	1.0mV	5.0mV	5μA	4μA
Conversion speed	240μs/2 channels or less (Sampling: 80μs/1 channel)					
Absolute maximum output	Voltage: ±12V Current: +28mA					
Output short protection	Present					
Analog output points	2 channels					
Offset/gain adjustment	Adjust the two channels simultaneously with the control knob on the front side of the module. The adjustment should be done on-line.					
A/D conversion	Analog input			Digital output		
	Voltage: -10 to 0 to 10VDC (Input resistance: 1MΩ) Current: 0 to 20mA (Input resistance: 250Ω)			0 to 4095 (12-bit binary value)		
I/O characteristics	0 to 10V range	0 to 5V range	1 to 5V range	-10 to 10V range	0 to 20mA range	4 to 20mA range
	0V	0V	1V	-10V	0mA	4mA
	2.5V	1.25V	2V	-5V	5mA	8mA
	5V	2.5V	3V	0V	10mA	12mA
	7.5V	3.75V	4V	5V	15mA	16mA
10V	5V	5V	10V	20mA	20mA	
Maximum resolution	2.5mV	1.25mV	1.0mV	5.0mV	5μA	4μA
Conversion speed	400μs/4 channels or less (Sampling: 80μs/1 channel)					
Absolute maximum input	Voltage: ±15V Current: ±30mA					
Analog input points	4 channels					
Offset/gain adjustment	Adjust the four channels simultaneously with the control knob on the front side of the module. Check the digital output value on-line while making the adjustments.					
Overall accuracy	D/A conversion (accuracy against the maximum value)		Voltage output (All ranges)		Current output (All ranges)	
	±1.0% (±100 mV)		±1.0% (±100 μA)		±1.0% (±40)	
Insulation method	Photocoupler isolation between I/O terminals and the PLC power supply. Between each channel: No isolation					
Number of occupying I/O points	64 points (Input 64 points, output 64 points)					
Connecting terminal base	20-point terminal base (M3.5 × 7 screws)					
Applicable wire size	0.75 to 1.25mm <sup>2</sup>					
Applicable solderless terminal	R1.25 - 3 1.25 - YS3 2 - 3.5 2 - YS3A V1.25 - M3 V1.25 - YS3A V2 - S3 V2 - YS3A					
Internal current consumption (5VDC)(A)	0.21					
External power supply	Voltage (V)	21.6DC to 26.4DC				
	Current consumption (A)	0.16				
Weight (kg)	0.33					


#### Point

When utilizing the peripheral device to assign the I/O numbers, set it as a 64-point output module.




Refer to the User's Manual of the PLC CPU for the general specifications.

### 3. Part Identification and Settings

#### 3.1 Part Identification



NO.	Name	Description
1)	RUN LED ○ RUN	Indicates the operating conditions of the A1S66ADA On: Power is ON Off: Power is OFF
2)	D/A conversion offset control knob D/A ⊖ OFFSET	Used when making a fine adjustment of the D/A conversion offset. The offset value is increased by turning the control knob to the right. The offset value is decreased by turning the control knob to the left.
3)	D/A conversion gain control knob D/A ⊖ GAIN	Used when making a fine adjustment of the D/A conversion gain. The gain value is increased by turning the control knob to the right. The gain value is decreased by turning the control knob to the left.
4)	A/D conversion offset control knob A/D ⊖ OFFSET	Used when making a fine adjustment of the A/D conversion offset. The offset value is increased by turning the control knob to the right. The offset value is decreased by turning the control knob to the left.
5)	A/D conversion gain control knob A/D ⊖ GAIN	Used when making a fine adjustment of the A/D conversion gain. The gain value is increased by turning the control knob to the right. The gain value is decreased by turning the control knob to the left.
6)	Analog output terminal (CH1, CH2)	Outputs the analog values (voltage/current) of CH1 to CH2. Refer to Section 5.2 on the wiring method.
7)	Analog input terminal (CH3 to CH6)	Inputs the analog values (voltage/current) of CH3 to CH6. Refer to Section 5.2 on the wiring method.
8)	Analog ground terminal	The ground terminal of the analog signal (Refer to Section 5.2 on the wiring method.)
9)	Frame ground terminal	The ground terminal of the shielded cable (Refer to Section 5.2 on the wiring method.)
10)	Power supply input terminal	Connect 24VDC at the input terminal of the power supply.
11)	Analog-output range switching setting pin	Set the analog output range. CH1, CH2 common. When setting the current output range, set as follows: When switching to 0 to 20 mA → Set a jumper at a position between 0 V and 5 V. When switching to 4 to 20 mA → Set a jumper at a position between 1 V and 5 V. Set the jumper as it always makes a line. (Set it with the jumper) (Setting at shipment: 0 to 10V range) (Example) When the analog output range is set to 0 to 10 V or 0 to 20 mA, the jumper should be set as follows.  When setting to 0 to 10 V When setting to 0 to 20 mA

NO.	Name	Description
12)	Analog-input voltage/current switching setting pin 	Set the analog input (voltage input or current input) for each channel (CH3 to CH6). (Set it with the jumper) (Setting at shipment : V) For voltage input setting : V For current input setting : I
13)	Analog-input range switching setting pin 	Set the analog output range. CH3 to CH6 common. When setting the current output range, set as follows: When switching to 0 to 20 mA → Set a jumper at a position between 0 V and 5 V. When switching to 4 to 20 mA → Set a jumper at a position between 1 V and 5 V. (Setting at shipment : 0 to 10V range) (Set it with the jumper) (Example) When the analog input range is set to -10 to 10 V or 4 to 20 mA, the jumper should be set as follows. 
14)	Terminal block	Numbers in a graphic indicate terminal numbers.

## 4. Loading and Installation

### 4.1 Handling Precautions


- Do not drop or put a great impact on the module case and the terminal block because they are made of resin.
- Do not take the printed circuit board of the module out of the case. It may result in a failure.
- Be careful not to let foreign matter such as filings or wire chips get inside the module while wiring. Remove all foreign matters if any get inside.
- Tighten the module installation screws and terminal screws within the range as follows:

Screw Area	Tightening Torque Range N·cm
Module fixing screws (M4 screw)	78 to 118N·cm
Terminal block terminal screws (M3.5 screw)	59 to 88N·cm
Terminal block installation screws (M4 screw)	78 to 118N·cm

### 4.2 Installation and Removal of the Shield Cover


It is necessary to install the shield cover when using Procedures for installing and removing the shield cover are described below.

#### (1) Installation



To install the shield cover to the module, install the cover to the terminal side first as shown in the figure, then it will be completed by pushing the cover to the module and tightening the shield fixing screw.

#### (2) Removal



To remove the cover from the module, remove the shield fixing screw first and insert the tip of a flat-tip screwdriver into the removal hole as shown in the figure, then move the screwdriver towards the rear of the module to separate the clip from the removal hole and remove the cover.

## 4.3 Installation Environment

Never install the A series in the following environments:


- Locations where the ambient temperature is outside the range of 0 to 55°C.
- Locations where the ambient humidity is outside the range of 10 to 90% RH.
- Locations where dew condensation takes place due to sudden temperature changes.
- Locations where there are corrosive and/or combustible gasses.
- Locations where there is a high level of conductive powder (such as dust and iron filings, oil mist, salt, and organic solvents).
- Locations exposed to the direct rays of the sun.
- Locations where strong power and magnetic fields are generated.
- Locations where vibration and shock are directly transmitted to the main module.

## 5.2 Wiring Between the A1S66ADA and the External Devices


The following shows the wiring method for the A1S66ADA.

- CH1 and CH2

#### (a) For voltage output



#### (b) For current output



\*1 Use a two-core twisted shield line for the power cable.

\*2 When noise or ripple occurs with the external cable, connect a condenser with 0.1 to 0.47μFVW to the input terminal of the external device.

### Important

The voltage and current output can not be used simultaneously on the same channel.  
In the event it is used, the internal elements are destroyed; therefore always open unused terminals.

## 5. Wiring

The following describes the precautionary items on wiring as well as wiring to the external devices.


### 5.1 Precautions when Wiring

To obtain the maximum performance from the functions of A1S66ADA and improve the system reliability, a wiring with the high durability against the noise is required. The external wiring precautions described below make more improvement in the wiring not to be affected by the noise.


- Use separate cables for the AC and the analog input to the A1S66ADA, in order not to be affected by the AC side surge or conductivity.
- Do not bundle or place the cable close to the main circuit line, high voltage line or load carrying wires from other than the PLC. It is influenced more easily by the noise, surge, or conductivity.
- Place a one-point grounding on the PLC side for the shield line or shield cable. However, depending on the external noise conditions, it may be better to have a grounding externally.

- CH3 to CH6

#### (a) For voltage input



#### (b) For current input



\*1 Use a two-core twisted shield line for the power cable.

\*2 Indicates the A1S66ADA input resistance.

\*3 When noise or ripple occurs with the external cable, connect a condenser with about 0.1 to 0.47μF (25V or more voltage resistance parts) between the terminal V+ and V-.

\*4 The FG terminal of the power supply module should always be grounded.


\*5 Make sure to connect between the FG of the power supply module and the FG of A1S66ADA.

\*6 Due to noise in the environment, AG terminal may attain better accuracy when grounded.

### Point

The FG terminal of A1S66ADA and the FG terminal of the PLC power supply module are not connected.

## 6. External Dimensions Diagram



(Unit : mm)

### Warranty

Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; machine damage or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

#### For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi.
- This product has been manufactured under strict quality control. However, when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.

Country/Region	Sales office/Tel	Country/Region	Sales office/Tel
U.S.A	Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway Vernon Hills, IL 60061, U.S.A Tel : +1-847-478-2100 MELCO-TEC Rep. Com.e Assessoria Tecnica Ltda. Rua Correia Dias, 184, Edificio Paraiso Trade Center-8 andar Paraiso, Sao Paulo, SP Brazil Tel : +55-11-5908-8331	Hong Kong	Mitsubishi Electric Automation (Hong Kong) Ltd. 10th Floor, Manulife Tower, 169 Electric Road, North Point, Hong Kong Tel : +852-2887-8870
Brazil	MELCO-TEC Rep. Com.e Assessoria Tecnica Ltda. Rua Correia Dias, 184, Edificio Paraiso Trade Center-8 andar Paraiso, Sao Paulo, SP Brazil Tel : +55-11-5908-8331	China	Mitsubishi Electric Automation (Shanghai) Ltd. 4/F Zhi Fu Plaza, No.80 Xin Chang Road, Shanghai 200003, China Tel : +86-21-6120-0808
Germany	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8 D-40880 Ratingen, GERMANY Tel : +49-2102-486-0	Taiwan	Setsuyo Enterprise Co., Ltd. 6F No.105 Wu-Kung 3rd Rd. Wu-Ku Hsiang, Taipei Hsine, Taiwan Tel : +886-2-2259-2459
U.K	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Hertfordshire, AL10 8XB, U.K. Tel : +44-1707-278100	Korea	Mitsubishi Electric Automation Korea Co., Ltd. 1480-6, Gayang-dong, Gangseo-gu Seoul 157-200, Korea Tel : +82-2-3660-9552
Italy	Mitsubishi Electric Europe B.V. Italian Branch Centro Dir. Colleoni, Pal. Perseo-Ing. 2 Via Paracelso 12, I-20041 Agrate Brianza, Milano, Italy Tel : +39-039-60531	Singapore	Mitsubishi Electric Asia Pte. Ltd. 307 Alexandra Road #05-01/02, Singapore 159943 Tel : +65-6470-2460
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carmetera de Rubi 76-80, E-08190 Sant Cugat del Valles, Barcelona, Spain Tel : +34-93-565-3131	Thailand	Mitsubishi Electric Automation (Thailand) Co. Ltd. Bang-Chan Industrial Estate No.111 Moo 4, Serithai Rd. T. Kamnayang, A. Kamnayang, Bangkok 10230 Thailand Tel : +66-2-517-1328
France	Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, F-92741 Nanterre Cedex, France TEL : +33-1-5568-5568	Indonesia	P.T. Autoteknikno Sumber Makmur Muara Karang Selatan, Block A/Utara No.1 Kav. No.11 Kawasan Industri Pergudangan Jakarta - Utara 14440, P.O.Box 5045 Jakarta, 11050 Indonesia Tel : +62-21-6630833
South Africa	Circuit Breaker Industries Ltd. Private Bag 2016, ZA-1600 Isando, South Africa Tel : +27-11-928-2000	India	Messung Systems Pvt. Ltd. Electronic Sadan NO/III Unit No15, M.I.D.C. Bhasan, Pune-411026, India Tel : +91-20-2712-3130
		Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, Rydalmere, N.S.W.2116, Australia Tel : +61-2-9684-7777

MITSUBISHI ELECTRIC CORPORATION  
HEAD OFFICE : TOKYO BUILDING, 2-73 MARUNOUCHI, CHYODOKU-KU, TOKYO 100-8555, JAPAN  
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HISASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.  
Printed in Japan on recycled paper.